





# Electrolux

# Ease C2




### 1


\* Certain models only | Suivant les modèles | فقط بعض الموديلات | Само определени модели | Pouze u některých modelů | Nur bestimmte Modelle  
 Kun på visse modeller | Ainult kindlad mudelid | Solo algunos modelos | فقط برای بعضی مدلها | Vain tietyt mallit | Ορισμένα μόνο μοντέλα  
 Samo određeni modeli | Csak egyes típusoknál | Solo per alcuni modelli | Tik tam tikriems modeliams | Tikai noteiktiem modeļiem | Kun enkelte modeller  
 Tylko niektóre modele | Doar pentru anumite modele | Только отдельные модели | Bara vissa modeller | Le določeni modeli | Len určité modely  
 Само код одређених модела | Yalnızca bazı modellerde | Залежно від моделі





### 2




### 3



### 4




### 5




### 6


**R** Recommended nozzle | Brosse recommandée | الفوارة الموصى بها | Препоръчителна дюза | Doručovaná hubice | Empfohlene Düse | Anbefalet mundstykke  
 Soovituslik otsak | Cepillo recomendado | نازلهاى توصيه شده | Suositeltava suulake | Συνιστώμενο ακροφύσιο | Preporučeni nastavak | Ajánlott szívófej  
 Spazzola consigliata | Rekomenduojamas antgalis | Leteicams uzgalis | Anbefalt munnstykke | Zalecana dysza | Perie recomandată | Рекомендованная насадка  
 Rekomenderat munstykke | Priporočni nastavek | Odporučaná hubica | Препоручени наставак | Önerilen başlık | Рекомендована насадка



### 7



### 8



### 9



[www.electrolux.com/shop](http://www.electrolux.com/shop)